

Z CAM SERIES





1

Kit No : BTZ60001
OEM No : 6812115 - 3097092 - 1696444 - 5001868113 - 9C462296
Description : Return Spring
 1- BTT251 Return Spring



1

Kit No : BTZ60003
OEM No : 3090997 - 1081819
Description : Adjusting Pinion
 1- BTT253 Pinion (Left)



1

Kit No : BTZ60005
OEM No : 68191219 - 272910 - 5001868121 - 9C462458AA
Description : Cross Shaft
 1- BTT255 Shaft



1

Kit No : BTZ60007
OEM No : 68192566 - 272908 - 3097100 - 8550977 - 9C462A105BA
Description : Adjusting Gear
 1- BTT257 Adjusting Gear (Right)



1

Kit No : BTZ60002
OEM No : 368192487 - 0972299 - 1698346 - 9C46206
Description : Return Spring Pin
 1- BTT252 Pin



1

Kit No : BTZ60004
OEM No : 3090998 - 1081820
Description : Adjusting Pinion
 1- BTT254 Pinion (Right)



1

Kit No : BTZ60006
OEM No : 64225252 - 1696446 - 5001868120 - 9C462B003AA
Description : Thrust Pin
 1- BTT256 Pin



1

Kit No : BTZ60008
OEM No : 68192565 - 272909 - 3097099 - 8550978 - 9C462A105AA
Description : Adjusting Gear
 1- BTT258 Adjusting Gear (Left)



Kit No	: BTZ60014
OEM No	: 68191541 - 276098 - 9C462K400BA
Description	: Reverse Lock Repair Kit (Right)
1- BTS83	Locking Shim
2- BTY37	Locking Spring



Kit No	: BTZ60015
OEM No	: 68191540 - 276097 - 9C462K400AA
Description	: Reverse Lock Repair Kit (Left)
1- BTS84	Locking Shim
2- BTY29	Locking Spring



Kit No	: BTZ60009
OEM No	: 272904
Description	: Adjusting Gear Cap
1- BTS85	Gear Cap



Kit No	: BTZ60010
OEM No	: 276099
Description	: Lock Cap Repair Kit (Thick Thread)
1- BTK90	O-Ring
2- BTT259	Pin
3- BTK91	O-Ring
4- BTT268	Cap (Thick Thread)
5- BTK92	O-Ring



Kit No	: BTZ60011
OEM No	: 68191219 - 272910 - 5001868121 - 9C462458AA
Description	: Cross Shaft
1- BTK90	O-Ring
2- BTT259	Pin
3- BTK91	O-Ring
4- BTT260	Cap (Thin Thread)
5- BTK92	O-Ring



Kit No	: BTZ60012
OEM No	: 64225252 - 1696446 - 5001868120 9C462B003AA
Description	: Thrust Pin
1- BTK93	O-Ring
2- BTT261	Pin
3- BTK94	O-Ring
4- BTT262	Cap (Without Tube)



Kit No : BTZ60018
OEM No : 68191511 - 1696925 - 272907 -
 5001868125 - 9C462K161AA
Description : Pinion (New Model)
 1- BTT264 Pinion (Right)



Kit No : BTZ60020
OEM No : 68191511 - 1696925 - 5001868125
Description : Pinion (Old Model)
 1- BTT266 Pinion (Left)



Kit No : BTZ60013
OEM No : 1696449 - 1696450
Description : Cover
 1- BTT263 Cover



Kit No : BTZ60016
OEM No : 68192410 - 3090954 - 1696448 -
 5001868119 - 9C462B009AA
Description : Dust Cover
 1- BTK95 Dust Cover




Kit No : BTZ60019
OEM No : 68191510 - 1696924 - 272906 -
 5001868126 - 9C462K161BA
Description : Pinion (New Model)
 1- BTT265 Pinion (Left)



Kit No : BTZ60021
OEM No : 68191511 - 1696925 - 5001868125
Description : Pinion (Old Model)
 1- BTT267 Pinion (Right)



Kit No : BTZ60022
OEM No : 1696450
Description : Gasket
 1- BTCN4 Gasket



Kit No : BTZ60017
OEM No : 272905
Description : Gasket Kit
 1- BTCN4 Gasket
 2- BTK89 Seal
 3- BTK96 Seal
 4- BTK97 O-Ring
 5- BTK98 O-Ring
 6- BTK99 O-Ring



Kit No : BTZ60023
OEM No : 5001 868 128 - 681 92 612

Description : Spring Holder
 1- BTS119 Spring Holder



Kit No : BTZ60025
OEM No : 5001 868 162 - 682 00 114

Description : Seal Sac
 1- BTK155 Seal



Kit No : BTZ60024
OEM No : 1517531 - 5001 868 163 - 681 91 518
 1088812

Description : Bushing Sac
 1- BTB34 Bushing



Kit No : BTZ60026
OEM No : 272904

Description : Adjusting Gear Cap Set
 1- BTS85 Gear Cap
 2- BTK91 O-Ring

